


Non-optic blow-yank-blown



1. standard set-up

2. attach blowhose, reheat behind the door

3. marver tip on bench right arm

4. pincer a point on the tip, start the neck

5. with dia. shears pull 1", then cradle the end [optional reheat here]

6. blow (hard), yank 2", softly blow

7. (with jacks) begin trimming the tail, continue the neck, then alternate between the two; during all of this blow gently then harder - but stop blowing if the bottom is losing its thickness (at all cost keep the bottom thicker than the sides!)

8. optional reheat if it's needed to complete step 7

9. reheat the outer (lower) half of the 'cylinder'

10. touch the jacks to the sides with the blades parallel to the floor (for a cylinder), blow gently then harder

(cont.)

11. reheat the bottom
12. Flatten the bottom (blow gently while pressing flat the bottom, touch the sides with the jack blades (level for a cylinder) if needed to remove any unwanted bulge in the sides. Make sure the bottom is slightly concave.
13. cool the punt site with a long but inaudibly soft blow with the soffietto, flash the whole piece.
14. transfer to punt
15. initiate 'opening process'